

## **Motorcycle Adapter Non-Slip (Part #5150320)**

1. Remove Main Shaft & Allen Bolt
2. Install MCycle Non Slip Assembly & MCycle Shaft onto Main Shaft



3. Install spring onto MCycle Shaft



**4. Install correct fitting inner cone on MCycle Shaft**



**5. Place MCycle wheel onto MCycle Shaft**



6. Install correct fitting outer cone, spacers & retaining nut onto MCycle Shaft



7. Set balancer to "Static" mode.